

LAND ROVER

LAND ROVER FREELANDER I (L314)

Modello	Anno di Produzione	Cil	KW	CV	Cilindri	Alimentazione	Codice Motore
FREELANDER I (L314)	1998-02-01 - 2000-11-01	1796 ccm	88 KW	120 CV	4 Cilindri	Benzina	18 K4F
FREELANDER I (L314)	1998-02-01 - 2000-11-01	1994 ccm	72 KW	98 CV	4 Cilindri	Diesel	20 T2N
FREELANDER I (L314)	1998-04-01 - 2006-10-01	1796 ccm	86 KW	117 CV	4 Cilindri	Benzina	18 K4F
FREELANDER I (L314)	2000-11-01 - 2006-10-01	2497 ccm	130 KW	177 CV	6 Cilindri	Benzina	25 K4F
FREELANDER I (L314)	2000-11-01 - 2006-10-01	1951 ccm	82 KW	112 CV	4 Cilindri	Diesel	204D3
FREELANDER I (L314)	2000-11-01 - 2006-10-01	1951 ccm	82 KW	112 CV	4 Cilindri	Diesel	M 47
FREELANDER I (L314)	2001-03-01 - 2006-10-01	1951 ccm	80 KW	109 CV	4 Cilindri	Diesel	204D3

LAND ROVER FREELANDER I Soft Top (L314)

Modello	Anno di Produzione	Cil	KW	CV	Cilindri	Alimentazione	Codice Motore
FREELANDER I Soft Top (L314)	1998-02-01 - 2006-10-01	1796 ccm	88 KW	120 CV	4 Cilindri	Benzina	18 K4F
FREELANDER I Soft Top (L314)	1998-02-01 - 2006-10-01	1994 ccm	72 KW	98 CV	4 Cilindri	Diesel	20 T2N