

# CITROËN

## CITROËN XANTIA (X1\_, X2\_)

| Modello           | Anno di Produzione      | Cil      | KW     | CV     | Cilindri   | Alimentazione | Codice Motore    |
|-------------------|-------------------------|----------|--------|--------|------------|---------------|------------------|
| XANTIA (X1_, X2_) | 1993-03-01 - 1995-05-01 | 1998 ccm | 95 KW  | 129 CV | 4 Cilindri | Benzina       | RFX XU10J2C/Z L3 |
| XANTIA (X1_, X2_) | 1993-03-01 - 1998-01-01 | 1761 ccm | 74 KW  | 101 CV | 4 Cilindri | Benzina       | LFZ (XU7JP)      |
| XANTIA (X1_, X2_) | 1993-03-01 - 1998-01-01 | 1998 ccm | 112 KW | 152 CV | 4 Cilindri | Benzina       | RFY (XU10J4/Z)   |
| XANTIA (X1_, X2_) | 1993-03-01 - 2001-03-01 | 1580 ccm | 65 KW  | 88 CV  | 4 Cilindri | Benzina       | BFZ (XU5JP)      |
| XANTIA (X1_, X2_) | 1993-03-01 - 2003-04-01 | 1998 ccm | 89 KW  | 121 CV | 4 Cilindri | Benzina       | RFX (XU10J2C)    |
| XANTIA (X1_, X2_) | 1994-06-01 - 1998-01-01 | 1998 ccm | 110 KW | 150 CV | 4 Cilindri | Benzina       | RFT (XU10J4/Z)   |
| XANTIA (X1_, X2_) | 1995-06-01 - 2001-12-01 | 1761 ccm | 81 KW  | 110 CV | 4 Cilindri | Benzina       | LFY (XU7JP4)     |
| XANTIA (X1_, X2_) | 1995-06-01 - 2003-04-01 | 1998 ccm | 108 KW | 147 CV | 4 Cilindri | Benzina       | RGX (XU10J2TE)   |
| XANTIA (X1_, X2_) | 1995-06-01 - 2003-04-01 | 1998 ccm | 97 KW  | 132 CV | 4 Cilindri | Benzina       | RFV (XU10J4R)    |
| XANTIA (X1_, X2_) | 1997-01-01 - 2003-04-01 | 2946 ccm | 140 KW | 190 CV | 6 Cilindri | Benzina       | XFZ (ES9J4)      |
| XANTIA (X1_, X2_) | 1997-04-01 - 2003-04-01 | 1761 ccm | 66 KW  | 90 CV  | 4 Cilindri | Benzina       | LFX (XU7JB)      |

## CITROËN XANTIA Break (X1\_, X2\_)

| Modello                 | Anno di Produzione      | Cil      | KW     | CV     | Cilindri   | Alimentazione | Codice Motore  |
|-------------------------|-------------------------|----------|--------|--------|------------|---------------|----------------|
| XANTIA Break (X1_, X2_) | 1995-06-01 - 1998-01-01 | 1761 ccm | 74 KW  | 101 CV | 4 Cilindri | Benzina       | LFZ (XU7JP)    |
| XANTIA Break (X1_, X2_) | 1995-06-01 - 2003-04-01 | 1998 ccm | 108 KW | 147 CV | 4 Cilindri | Benzina       | RGX (XU10J2TE) |
| XANTIA Break (X1_, X2_) | 1995-06-01 - 2003-04-01 | 1998 ccm | 89 KW  | 121 CV | 4 Cilindri | Benzina       | RFX (XU10J2C)  |
| XANTIA Break (X1_, X2_) | 1995-06-01 - 2003-04-01 | 1998 ccm | 97 KW  | 132 CV | 4 Cilindri | Benzina       | RFV (XU10J4R)  |
| XANTIA Break (X1_, X2_) | 1995-06-01 - 2003-04-01 | 1761 ccm | 81 KW  | 110 CV | 4 Cilindri | Benzina       | LFY (XU7JP4)   |
| XANTIA Break (X1_, X2_) | 1997-04-01 - 2003-04-01 | 1761 ccm | 66 KW  | 90 CV  | 4 Cilindri | Benzina       | LFX (XU7JB)    |
| XANTIA Break (X1_, X2_) | 1998-01-01 - 2003-04-01 | 2946 ccm | 140 KW | 190 CV | 6 Cilindri | Benzina       | XFZ (ES9J4)    |